



FLAT PLATTER
 M 0307 31.0 cm.

FLAT PLATE
 M 0301 27.0 cm.
 M 0302 24.0 cm.
 M 0303 21.0 cm.
 M 0304 18.0 cm.
 M 0305 16.0 cm.



SOUP PLATE
 M 0306 23.0 cm.



PASTA PLATE
 M 0308 31.0 cm.
 M 0309 28.0 cm.



BOWL
 M 0340 12.0x12.5 cm.
 M 0341 15.0x15.5 cm.
 M 0342 18.0x18.5 cm.
 M 0343 20.0x21.5 cm.



NOODLE BOWL
 M 0325 17.0 cm.



BOWL
 M 0326 15.0 cm.



CEREAL BOWL
 M 0327 14.0 cm.



BOWL
 M 0328 13.0 cm.
 M 0329 11.0 cm.



SOUP CUP 2 HDLS.
 M 0316 0.30 ltr.
SAUCER
 M 0317 16.0 cm.
 M 0313 15.0 cm.



COFFEE CUP
 M 0310 0.25 ltr.
SAUCER
 M 0313 15.0 cm.



TEA CUP
 M 0311 0.23 ltr.
SAUCER
 M 0313 15.0 cm.



COFFEE POT WITH LID
 M 0318/L 0.5 ltr.



TEA POT WITH LID
 M 0319/L 0.6 ltr.



SUGAR BOWL WITH LID
 M 0320/L 11.0 cm.



CREAMER
 M 0323 0.20 ltr.
 M 0324 0.10 ltr.



SUGAR PACK HOLDER
 M 0321 7.0 X 10.0 X 4.3 cm.
 M 0322 7.0 X 7.5




CAPPUCINO CUP
 M 0312 0.3 ltr.
SAUCER
 M 0317 16.0 cm.



ESPRESSO CUP
 M 0314 0.10 ltr.
ESPRESSO CUP SAUCER
 M 0315 12.0 cm.



THICK SAUCE DISH
 M 0330 9.0 cm.



LONG TRAY
 M 0338 10.0 X 40.0 cm.
 M 0337 12.0 X 47.0 cm.



CONDIMENT TRAY
 M 0334 8.5 X 22.5 cm.
 M 0333 8.5 X 30.0 cm.



CONDIMENT BOWL
 M 0332/L 0.06 ltr.



VINEGAR / SOYA SAUCE POT
 M 0336/L 0.10 ltr.



SPICE SPOON
 M 0335 2.5x8.0 cm.



DIVIDED SAUCE DISH
 M 0331 5.0x11.0 cm.



CANAPE & SOY SAUCE DISH
 M 0339 7.5 cm.



SALT SHAKER
 M 0344 4.0 X 4.0 X 7.7 cm.



PEPPER SHAKER
 M 0345 4.0 X 4.0 X 7.7 cm.



EGG CUP / TOOTHPICK HOLDER
 M 0346 4.7 X 4.9 X 7.3 cm.