



ROUND PLATTER
P 7307 31.5 cm. (12 3/8") 1,230 g.
P 7308 30.0 cm. (11 7/8") 1,070 g.



FLAT PLATE
P 7301 28.0 cm. (11 1/8") 775 g.
P 7302 26.0 cm. (10 1/4") 755 g.
P 7303 23.0 cm. (9 1/8") 560 g.
P 7304 21.5 cm. (8 1/2") 430 g.
P 7305 17.5 cm. (6 7/8") 310 g.
P 7341 16.0 cm. (6 1/4") 215 g.



SOUP BOWL
P 7306 23.0 cm. (9 1/8") 620 g.



PASTA BOWL
P 7309 28.0 cm. (11 1/8") 1,067 g.



GOURMET BOWL
P 7338 28.0 cm. (11 1/8") 1,000 g.



BANQUET PLATE
P 7339 28.0 cm. (11 1/8") 832 g.
P 7352 30.0 cm. (11 7/8") 1,120 g.



COFFEE & TEA POT WITH LID
P 7323/L 1.13 ltr. (39.78 oz.) 670 g.



COFFEE & TEA POT WITH LID
P 7324/L 0.54 ltr. (18.83 oz.) 398 g.



SUGAR BOWL WITH LID
P 7325/L 0.28 ltr. (9.86 oz.) 248 g.



SUGAR PACK HOLDER
P 7326 6.5 x 10.5 cm. (2 1/2" x 4 1/8") 155 g.




CREAMER
P 7327 0.28 ltr. (9.86 oz.) 235 g.
P 7328 0.15 ltr. (5.28 oz.) 135 g.
P 7329 0.09 ltr. (2.99 oz.) 95 g.




TEA CUP
P 7321 0.25 ltr. (8.80 oz.) 240 g.
TEA CUP SAUCER
P 7315 Ø 16.0 cm. (6 1/4") 240 g.



COFFEE CUP
P 7313 0.265 ltr. (9.15 oz.) 225 g.
P 7314 0.23 ltr. (7.92 oz.) 200 g.
COFFEE CUP SAUCER
P 7315 Ø 16.0 cm. (6 1/4") 240 g.



COFFEE CUP STACKABLE
P 7318 0.30 ltr. (10.38 oz.) 250 g.
P 7319 0.24 ltr. (8.45 oz.) 205 g.
COFFEE CUP SAUCER
P 7315 Ø 16.0 cm. (6 1/4") 240 g.



ESPRESSO CUP
P 7316 0.10 ltr. (3.34 oz.) 106 g.
ESPRESSO CUP STACKABLE
P 7320 0.10 ltr. (3.52 oz.) 110 g.
ESPRESSO CUP SAUCER
P 7317 Ø 12.5 cm. (4 7/8") 116 g.



TEA POT WITH LID
P 7344/L 0.45 ltr. (15.84 oz.) 349 g.



COFFEE POT WITH LID
P 7343/L 0.45 ltr. (15.84 oz.) 341 g.



CREAMER
P 7345 0.10 ltr. (3.34 oz.) 90 g.



MUG STACKABLE
P 7322 0.34 ltr. (11.97 oz.) 300 g.



COCKTAIL BOWL
P 7340 11.0 X 17.0 cm. (4 3/8" X 6 3/4") 230 g.



SUGAR PACK HOLDER
P 7346 7.0 X 8.0 X 5.5 cm.
(2 3/4" X 3 1/4" X 2 1/8") 160 g.



SALT SHAKER
P 7347 6.0 cm. (2 3/8") 60 g.
PEPPER SHAKER
P 7348 6.0 cm. (2 3/8") 60 g.



TOOTHPICK HOLDER
P 7349 5.0 cm. (2") 52 g.



OVAL PLATTER
P 7310 28.5 x 40.0 cm. (11 1/4" x 15 3/4") 1,490 g.
P 7311 23.5 x 33.0 cm. (9 1/4" x 13") 835 g.



PICKLE DISH
P 7312 17.0 x 23.5 cm. (6 3/4" x 9 1/4") 370 g.




SALAD BOWL
P 7330 Ø 24.5 cm. (9 5/8") 1,340 g.
P 7331 Ø 21.0 cm. (8 1/4") 950 g.
SALAD BOWL / NOODLE BOWL
P 7332 Ø 18.0 cm. (7 1/8") 600 g.



CEREAL BOWL
P 7333 Ø 14.0 cm. (5 1/2") 310 g.



FRUIT BOWL
P 7334 Ø 13.5 cm. (5 3/8") 195 g.



RICE BOWL
P 7335 Ø 11.0 cm. (4 3/8") 176 g.




BOUILLON / STACKABLE BOWL
P 7336 Ø 11.0 cm. (4 3/8") 245 g.



SAUCE DISH
P 7337 Ø 9.0 cm. (3 1/2") 76 g.



SQUARE BUTTER DISH
P 7351 8.0 X 8.0 cm. (3 1/8" X 3 1/8") 60 g.



ROUND BUTTER DISH
P 7350 Ø 6.5 cm. (2 1/2") 55 g.

Size could be varied ± 2 percent
Capacity could be varied ± 10 percent