



COUPE PLATTER
(Parallel)
P 7517 31.6 cm.



OVAL COUPE PLATE
(Parallel)
P 7528 45.5 x 33.5 cm. (18")
P 7529 40.5 x 30.5 cm. (16")
P 7530 35.5 x 26.0 cm. (14")
P 7531 30.5 x 22.5 cm. (12")
P 7532 27.0 x 20.0 cm. (10 3/4")



OVAL COUPE PLATE
(Spiral)
P 7508 36.8 cm. (14.5")
P 7509 31.8 cm. (12.5")



OVAL PLATTER
P 1615 36.0 cm.
P 1614 32.0 cm.



NOODLE BOWL
P 7564 17.0 cm.



COFFEE POT
P 7554/L 0.50 Ltr.



TEA POT
P 7555/L 0.60 Ltr.



GRAVY BOAT
P 7562 0.15 L.



GOURMENT PLATE
(Parallel)
P 7521 28.0 cm.
P 7522 26.0 cm.



STEAK PLATE
(Parallel)
P 7524 28.0 cm.



COUPE PLATTER
(Spiral)
P 7505 31.6 cm.



ROUND PLATE
PLATTER
P 1635 31.0 cm.



BOWL/CEREAL BOWL
P 7565 15.0 cm.
P 7566 14.0 cm.



COFFEE CUP
(Footed)
P 1034 0.21 L.



TEA CUP
P 7544 0.23 L.



VINEGAR SAUCE POT
P 7572/L 0.12 L.



GOURMENT PLATE
(Parallel)
P 7523 25.0 cm.



APPITIZER PLATE
(Parallel)
P 7525 21.0 cm.



COUPE PLATE
(Spiral)
P 7501 28.0 cm.
P 7502 24.0 cm.
P 7503 21.0 cm.
P 7504 16.0 cm.



FLAT PLATE
P 1634 26.0 cm.
P 1601 24.0 cm.
P 1602 21.0 cm.
P 1604 18.0 cm.
P 1603 19.5 cm.



TULIP BOWL
P 7563 15.0 cm.



TALL CUP
P 7541 0.25 L.



CAPPUCINO CUP
P 7545 0.30 L.



CONDIMENT POT
P 7573/L 0.08 L.



COUPE DEEP PLATE
(Parallel)
P 7526 26.5 cm.
P 7527 21.5 cm.



SQUARE PLATE
(Parallel)
P 7533 29.0 x 29.0 cm.
P 7534 22.0 x 22.0 cm.



GOURMENT BOWL
(Spiral)
P 7506 28.0 cm.
P 7507 26.0 cm.



DEEP PLATE
P 1636 21.0 cm.



BOWL with Lid
P 7567/L 13.0 cm.



COFFEE CUP
P 7539 0.23 L.




SAUCER - Parallel
P 7546 15.0 cm.



CONDIMENT TRAY - Parallel
P 7574 8.0 x 29.0 cm.



COUPE PLATE
(Parallel)
P 7510 28.0 cm.
P 7511 26.0 cm.
P 7512 24.0 cm.
P 7513 21.0 cm.
P 7514 18.5 cm.
P 7515 16.0 cm.



RECTANGULAR PLATE
(Parallel)
P 7535 23.0 x 30.0 cm.



SALAD/CEREAL BOWL
P 1618 21.0 cm.
P 1617 12.0 cm.



PICKLE DISH
P 1626 21.0 cm.



BOWL
P 7568 11.5 cm.
P 7569 10.5 cm.



COFFEE CUP
P 7540 0.23 L.



CREAMER
P 7559 0.19 L.
P 7560 0.10 L.



SPICE SPOON
P 4195 2.5 x 7.5 cm. (1"x2 3/4")



SALAD BOWL
(Parallel)
P 7519 25.0 cm.



LONG TRAY
(Parallel)
P 7536 13.0 x 47.0 cm.
P 7537 11.0 x 40.0 cm.



COFFEE CUP SAUCER
P 1637 16.0 cm.



CAKE PLATE
P 1616 28.0 cm.



SUGAR PACK HOLDER
(Calla Lily)
P 7556 6.5 x 7.1 x 7.6 cm.



STACKING CAN CUP
P 7542 0.27 L.




CREAMER W/O
HANDLE
P 7561 0.50 L.



SPOON & CHOPSTICK REST
P 7578 7.5 x 9.5 cm.



SOUP PLATE
(Parallel)
P 7516 23.0 cm.



STACKING SOUP CUP
2 HDLS.
P 7549 0.30 cc.



STACKING SOUP CUP
W/O HDLS.
P 7550 0.30 L.



FUSION MUG
P 7552 0.35 L. (12 oz.)
P 7553 0.38 L. (13 oz.)



SAUCER
(Parallel)
P 7546 15.0 cm.



SAUCE DISH
P 7570 7.0 x 7.5 cm.
P 7571 8.0 x 8.5 cm.



SUGAR PACK HOLDER
(Drip)
P 7557 7.0 x 8.5 x 8.0 cm.



STACKING COFFEE CUP
P 7543 0.20 L.



SALT SHAKER
P 7575
PEPPER SHAKER
P 7576



SUGAR PACK HOLDER
(Oval)
P 7558 5.2 x 10.5 x 5.4 cm.



ESPRESSO CUP
P 7547 0.1 L.



ESPRESSO CUP SAUCER
(Parallel)
P 7548 11.0 cm.



TOOTHPIC HOLDER
P 7577